






<h3>2.4G PS5 Wireless Controller Instruction Manual</h3>  <p>CM-048</p>	<h4>Contents</h4> <ul style="list-style-type: none"> Product Specifications 1 Package Contents 1 Product Overview 2 Function Introduction 3 PS5&PC Connection 4 PS5&PC Reconnection 5 PS5 Connection 6 USB Connection 7 Android Connection 8 Setup Procedure 9 Key Mapping 10 Cancel Single Key Mapping 11 Cancel All Key Mapping 12 Cancel Single Rapid Fire 13 Cancel All Rapid Fire 14 Adjust Rapid Fire Rate 15 Combo Key (Macro Programming) 16 Cancel Single Combo Key 17 Cancel All Combo Key 18 Troubleshooting 20 Appendix 21 After-Sales Support 22 	<p>Note: This product is a third-party product. In case of any issue, please contact the supplier to ensure it works properly.</p>  <p>Product Specifications</p> <p>Package Contents</p> <ul style="list-style-type: none"> Wireless Controller X1 Adapter X1 USB Charging Cable X1 Instruction Manual X1 	<h4>Product Concept</h4> 	<h4>Function Introduction</h4> <h5>Charging Prompt</h5> <ol style="list-style-type: none"> When the controller is powered off and the USB charging cable is plugged in, the controller indicator light will glow, and once fully charged, the light will go off. When the controller is connected and the USB charging cable is plugged in, the controller indicator light will stay on continuously, and once fully charged, the light will stay on continuously. <h5>Sleep Mode</h5> <p>When the controller is connected to the receiver and there is no button or joystick activity for 30 minutes, the receiver will automatically disconnect from the controller. The controller will enter sleep mode automatically, and the receiver will not respond to any commands.</p> <h5>Controller Vibration</h5> <p>On the PS5&PC platform, the controller has vibration functionality to provide corresponding feedback based on the requirements of different in-game scenarios.</p> <h5>Motion/Touch Functionality</h5> <p>Support motion and touch functions on the controller on PS5/PS4 console.</p> <h5>Video/Stereo Functionality</h5> <p>Support video/stereo function on PS5/PS4 console.</p>	<h4>PS5&PC Connection</h4> <p>For the PS5 Console to USB Cable Connection (PC requires no setup)</p>  <p>PS5 Console: PS5</p> <p>PC: PC</p> <p>2.4G Adapter: Adapter</p> <p>For the PS5 Console to Wireless Connection (PC requires no setup)</p>  <p>PS5 Console: PS5</p> <p>PC: PC</p> <p>2.4G Adapter: Adapter</p>
<p>Hold Share and Press B button until the light starts on.</p>  <p>PS5&PC Reconnection (Previously Connected Successfully)</p> <p>Plug the 2.4G Adapter into the PS5&PC USB-A port. The light flashes slowly.</p> 	<p>Press the Home button when the controller is in off state.</p>  <p>PS4 Connection</p> <p>Press the indicator light of 2.4G Adapter and Controller stay on, connected successfully.</p> <p>PS4 Connection</p> <ol style="list-style-type: none"> Press the indicator light of 2.4G Adapter and Controller stay on, connected successfully. Press the "PS" button on the controller to power it on, and the controller will connect to the PS4 console wirelessly. After the controller is connected to the PS4 console, the controller light will stay on. Press the combination button on the selected user to display the corresponding shared light on the console. 	<p>This controller only needs to be paired with the PS4 console once. For subsequent connections, simply power on the controller by pressing the "PS" button to connect to the PS4 console (provided it has been paired with another device).</p> <h4>IOS Connection</h4> <ol style="list-style-type: none"> Press the controller's powered off, press and hold the "SHARE" button and the "PS" button simultaneously for 3 seconds, and the indicator light will flash rapidly three times. On your iOS device, open the settings, select "Bluetooth," turn on Bluetooth, locate the Bluetooth name "Wireless Controller," tap to connect. Once connected, the light will stay on. This controller only needs to be paired with the iOS device once. For subsequent connections, simply power on the controller by pressing the "PS" button to connect (provided it has been paired with another device). 	<h4>Android Connection</h4> <ol style="list-style-type: none"> When the controller is powered off, press and hold the "SHARE" button and the "PS" button simultaneously for 3 seconds, and the indicator light will flash rapidly three times. On your Android device, open the settings, select "Bluetooth," turn on Bluetooth, locate the Bluetooth name "Wireless Controller," tap to connect. Once connected, the light will stay on. This controller only needs to be paired with the Android device once. For subsequent connections, simply power on the controller by pressing the "PS" button to connect (provided it has been paired with another device). 	<h4>Important Information Before Setting Up Functions</h4> <p>The key mapping/Function Center functions are only supported when using the PS5&PC platform.</p> <p>The same key cannot be shared between the rapid fire, key mapping, and cancel single key mapping.</p> <p>During the configuration process, each valid operation will trigger a vibration in the controller.</p> <p>*The Android/iOS platform does not support rapid fire, key mapping, and cancel key functions.</p>	<h4>Key Mapping</h4> <p>Press L3 and the D button simultaneously.</p>  <p>Press the mapped button, then press the source button (the source button: OPTICALLY/ANALOG/SHARE/PS button, e.g., press A, then press B, C, D, respectively, A, B, C, and then press the D button).</p>  <p>Press L3 button.</p> 

<h4>Cancel Single Key Mapping</h4> <p>Hold R2 button for 5S, the controller vibrates.</p>  <p>Press L3 and the D button simultaneously.</p>  <p>Press twice the button you want to cancel the mapping for, e.g., Press A, hold A to cancel A to default function.</p>  <p>Press L3 button.</p> 	<h4>Cancel All Key Mapping</h4> <p>Hold R2 button for 5S, the controller vibrates.</p>  <p>Press L3 and the D button simultaneously.</p>  <p>Hold L2 button for 5S.</p> 	<h4>Rapid Fire Function</h4> <p>Hold R2 button for 5S, the controller vibrates.</p>  <p>Press L3 and the X button simultaneously.</p>  <p>Press the button you want to rapid fire (the source button: OPTICALLY/ANALOG/SHARE/PS button).</p>  <p>Press L3 button.</p> 	<h4>Cancel Single Rapid Fire</h4> <p>Hold R2 button for 5S, the controller vibrates.</p>  <p>Press L3 and the X button simultaneously.</p>  <p>Press the button you want to cancel the rapid fire.</p>  <p>Press L3 button.</p> 	<h4>Cancel All Rapid Fire</h4> <p>Hold R2 button for 5S, the controller vibrates.</p>  <p>Press L3 and the X button simultaneously.</p>  <p>Hold L2 button for 5S.</p> 	<h4>Adjust Rapid Fire Rate</h4> <p>Save level: 5%, 10%, 15%, 20%, 25%, 30%, 35%, 40%, 45%, 50%, 55%, 60%, 65%, 70%, 75%, 80%, 85%, 90%, 95%, 100%.</p> <p>Press L3 and the X button simultaneously.</p>  <p>Press the "+" button to increase the rapid fire rate. Press the "-" button to decrease the rapid fire rate.</p>  <p>Press L3 button.</p> 
<h4>Combo Key (Macro Programming)</h4> <p>Hold R2 button for 5S, the controller vibrates.</p>  <p>Press any function key (that supports HOME/OPTION/SHARE buttons) and hold the press and release the key to key chain, wait until after 30 seconds of inactivity.</p>  <p>Press L3 button.</p>  <p>Press any button to set L3 as the control trigger (the support HOME/OPTION/SHARE/Touchpad/PlayStation buttons).</p> 	<h4>Cancel Single Combo Key</h4> <p>Hold R2 button for 5S, the controller vibrates.</p>  <p>Press L3 and the D button simultaneously.</p>  <p>Press L3 button.</p>  <p>Press the button that begins the combo.</p> 	<h4>Cancel All Combo Key</h4> <p>Hold R2 button for 5S, the controller vibrates.</p>  <p>Press L3 and the D button simultaneously.</p>  <p>Hold L2 button for 5S.</p> 	<h4>Precautions</h4> <ul style="list-style-type: none"> Do not use the product in dusty or high-temperature environments. Avoid strong magnetic, strong, vibrating, or dampening to disassemble the product to prevent electromagnetic damage. The product contains a built-in battery; do not throw the controller into the fire or dispose of with regular trash. Keep the controller away from water or other liquids as they may affect its functionality. Do not drag the controller over fire or other heat sources. Avoid placing heavy objects on the product. Do not touch the ports with your hands, and do not insert foreign objects into the ports. Improper use should not disassemble the product to avoid voiding the warranty. Children should use the product under adult supervision. 	<h4>Troubleshooting</h4> <p>Not compatible with PS5, what should I do? Ensure the PS5 console is set to USB Cable connection mode and that the controller is successfully paired with the 2.4G adapter.</p> <p>Why does it prompt me to update when I insert the 2.4G adapter? The PS5 console is not set to USB Cable connection mode (PS5 Console: "Setting" > "Accessories" > "Controller (Wireless)" > "Communication Method" > select "USB Cable").</p> <p>If I need to use the original PS5 controller wirelessly, do I need to switch the connection mode to Bluetooth? No. The original controller supports both wireless and wired connections. Setting the USB mode will not affect its wireless connection. Simply turn on the original controller, and it will reconnect automatically.</p> <p>Do I need to long-press to get away from sleep? No, you only need to just press successfully. Also, make sure the controller will automatically reconnect when powered on.</p> <p>How to solve any connection problems that occur? Try turning off the controller and re-pairing it with the 2.4G adapter. This usually effectively solves the connection problem.</p> <p>Others: If the controller fails to power on, it may be due to a depleted internal battery. Please recharge the controller using a USB cable to charge it before attempting to power on again. In case of unexplained controller freeze or disconnection, ensure that you are not too far from the device or by stabilizing the connection.</p>	<h4>For further assistance, contact us:</h4> <p>A. Service Email: Support-449@ps5wireless.com</p> <p>B. Or Contact the QR code to open contact.</p>  <p>C. Or Contact us on Amazon.</p> <p>*This is a third-party product. If it becomes incompatible after a console update, please contact us or email for the package, or visit the QR code to download the update package for installation.</p>